Disclaimer: This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications



# soft starter for asynchronous motor, Altistart 22, control 230V, 230 to 440V, 55 to 110kW

ATS22C21Q

Main	١

Range of product	Altistart 22			
Product or component type	Soft starter			
Product destination	Asynchronous motors			
Product specific application	Pumps and fans			
Component name	ATS22			
Network number of phases	3 phases			
[Us] rated supply voltage	pply voltage 230440 V - 1510 %			
Motor power kW	110 kW 400 V 110 kW 440 V 55 kW 230 V			
Factory setting current	195 A			
Power dissipation in W	117 W for standard applications			
Utilisation category	AC-53A			
Type of start Start with torque control (current limited to 3.5 ln)				
IcL starter rating	210 A for connection in the motor supply line for standard applications			
IP degree of protection	IP00			

## Complementary

Assembly style	With heat sink				
Function available	Internal bypass				
Supply voltage limits	195484 V				
Supply frequency         5060 Hz - 1010 %					
Network frequency 4566 Hz					
Device connection	To the motor delta terminals In the motor supply line				
[Uc] control circuit voltage	230 V - 1510 % 50/60 Hz				
Control circuit consumption	20 W				
Discrete output number	2				
Discrete output type	Relay outputs R1 230 V running, alarm, trip, stopped, not stopped, starting, ready C/O Relay outputs R2 230 V running, alarm, trip, stopped, not stopped, starting, ready C/O				
Minimum switching current 100 mA at 12 V DC (relay outputs)					

5 A 250 V AC resistive 1 relay outputs 5 A 30 V DC resistive 1 relay outputs 2 A 250 V AC inductive 0.4 20 ms relay outputs 2 A 30 V DC inductive 7 ms relay outputs				
3				
(LI1, LI2, LI3) logic, 5 mA 4.3 kOhm				
24 V <= 30 V				
Positive logic LI1, LI2, LI3 at State 0: < 5 V and <= 2 mA at State 1: > 11 V, >= 5 mA				
0.41 lcl adjustable				
750 Ohm				
Modbus				
1 RJ45				
Serial				
RS485 multidrop				
4800, 9600 or 19200 bps				
31				
Phase failure: line Thermal protection: motor Thermal protection: starter				
CE				
Forced convection				
Vertical +/- 10 degree				
425 mm				
206 mm				
299 mm				
33 kg				
55100 kW at 200240 V 3 phases 110220 kW at 380440 V 3 phases				
Soft starter				
Conducted and radiated emissions level A conforming to IEC 60947-4-2 Damped oscillating waves level 3 conforming to IEC 61000-4-12 Electrostatic discharge level 3 conforming to IEC 61000-4-2 Immunity to electrical transients level 4 conforming to IEC 61000-4-4 Immunity to radiated radio-electrical interference level 3 conforming to IEC 61000-4-3 Voltage/current impulse level 3 conforming to IEC 61000-4-5				
EN/IEC 60947-4-2				
CCC UL GOST CSA C-Tick				
1 gn (f= 13200 Hz) conforming to EN/IEC 60068-2-6 1.5 mm (f= 213 Hz) conforming to EN/IEC 60068-2-6				
15 gn for 11 ms conforming to EN/IEC 60068-2-27				
56 dB				
56 dB  Level 2 conforming to IEC 60664-1				
Level 2 conforming to IEC 60664-1				

Operating altitude	<= 1000 m without derating > 1000< 2000 m with current derating of 2.2 % per additional 100 m

## **Packing Units**

Unit Type of Package 1	PCE		
Number of Units in Package 1	1		
Package 1 Height	46.000 cm		
Package 1 Width	40.000 cm		
Package 1 Length	60.000 cm		
Package 1 Weight	24.500 kg		

# Offer Sustainability

REACh Regulation	REACh Declaration		
EU RoHS Directive	Pro-active compliance (Product out of EU RoHS legal scope) EU RoHS Declaration		
Mercury free	Yes		
China RoHS Regulation	China RoHS declaration		
RoHS exemption information	Yes		
WEEE	The product must be disposed on European Union markets following specific waste collection and never end up in rubbish bins		

## **Contractual warranty**


Warranty 18 months

# **ATS22C21Q**

**Dimensions Drawings** 

## Frame Size D

### **Dimensions**



## ATS22C21Q

Mounting and Clearance

#### **Precautions**

#### **Standards**

The Altistart 22 soft starter is compliant with pollution Degree 2 as defined in NEMA ICS1-1 or IEC 60664-1.

For environment pollution degree 3, install the Altistart 22 soft starter inside a cabinet type 12 or IP54.

### DANGER


HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

ATS22 soft starters are open devices and must be mounted in a suitable enclosure.

Failure to follow these instructions will result in death or serious injury.

#### **Air Circulation**

Leave sufficient free space to help the air required for cooling purposes to circulate from the bottom to the top of the unit.



### Overheating

To avoid the soft starter to overheat, respect the following recommendations:

- Mount the Altistart 22 Soft Starter within ± 10° of vertical.
- Do not locate the Altistart 22 Soft Starter near heat radiating elements.
- Electrical current through the Altistart 22 Soft Starter will result in heat losses that must be dissipated into the ambient air immediately surrounding the
- If several soft starters are installed in a control panel, arrange them in a row. Do not stack soft starters. Heat generated from the bottom soft starter ca

# ATS22C21Q

Mounting and Clearance

## Wall mounted or Floor-standing Enclosure with IP 23 Degree of protection


### Introduction

To help proper air circulation in the soft starter, grilles and forced ventilation can be installed.

### **Ventilation Grilles**



### **Forced Ventilation Unit**



# ATS22C21Q

Connections and Schema

### **Power Terminal**

### **Bar Style**



Power supply and output to motor	Bar	b	30 mm (1.18 in)
		а	5 mm (0.2 in)
		Bolt	M12 (0.47 in)
	Cable and protective cover	Size	2 X 150 mm²
		Gauge	2 X 250 MCM
		Protective cover	LA9F703
		Tightening torque	57 N.m
			498.75 lb.in

## Power connections, minimum required wiring section


IEC cable	UL cable
mm² (Cu 70°C/158°F) (1)	AWG (Cu 75°C/167°F) (1)
95	300 MCM

# **ATS22C21Q**

Connections and Schema

## 230 Vac control, logic Inputs (LI) 24 Vdc, 3-wire control


## With Line Contactor, Freewheel or Controlled Stop



# **ATS22C21Q**

Connections and Schema

230 Vac control, logic Inputs (LI) 24 Vdc, 2-wire control, freewheel stop



# **ATS22C21Q**


Connections and Schema

### Connection in the motor delta winding in series with each winding

### Wiring

ATS22 soft starters connected to motors with the delta connections can be inserted in series in the motor windings.

The following wiring requieres particular attention. It is documented in the Altistart 22 Soft start - soft stop unit user manual. Please contact Schneider Electric commercial organisation for further informations.



### Example


A 400 V - 110 kW motor with a line current of 195 A (nominal current for the delta connection). The current in each winding is equal to 195/1.5 or 130 A. The rating is determined by selecting the soft starter with a permanent nominal current (ICL) just above this current.

# ATS22C21Q

**Performance Curves** 

### **Motor Thermal Protection - Cold Curves**

### Curves



A Class 10 B Class 20 C Class 30

### Trip time for a Standard Application (Class 10)

	• •	•	,
3.5 ln			
32 s			

### Trip time for a Severe Application (Class 20)




# Trip time for a Severe Application (Class 30)

3.5 ln	
95 s	

**Performance Curves** 

### **Motor Thermal Protection - Warm Curves**

### **Curves**



# Trip time for a Standard Application (Class 10)

Class 30

	• •	•	•
3.5 ln			
16 s			

### Trip time for a Severe Application (Class 20)

3.5 ln	
32 s	

### Trip time for a Severe Application (Class 30)

3.5 ln	
48 s	

## Recommended replacement(s)